




Auto Air Valve Parts List



Item	Description	Qty
1	Cap	1
2	O Ring	1
3	Cover	1
4	Lock Nut 5/16" UNF	1
5	Flat Washer 8mm	2
6	Flat Washer	2
7	Diaphragm	1
8	Guide bush	1
9	O Ring	1
10	O Ring	1
11	Shaft	1
12	Flat Washer	1
13	Seat Holder	1
14	Rubber Gasket	1
15	Retainer	1
16	Lock Nut	1
17	Inner Bush	1
18	O Ring	1
19	Body	1
20	Spring Washer	4
21	Nut 1/4" UNC	4
22	Hex Head Machine Screw 1/4" UNC	4
23	Spring	1



Auto Air Valve Service Kit -


Part No.	Description	Parts Included
RCV1 RKT	Service Kit	2, 4, 5, 7, 9, 10, 12, 14, 16, & 18




Corsa I Air Operated Abrasive Valve – with Tungsten Sleeve



Item	Description	Qty
1	Top	1
2	Anti-Vibration Washer	1
3	Stop Ring	1
4	Spring	1
5	Piston Seal	1
6	Plunger Cover	1
7	Nylon Washer	1
8	Piston	1
9	Tungsten Plunger	1
10	Cylinder	1
11	Plunger Seal	4
12	O-Ring	2
13	Bush	1
14	Urethane Sleeve	1
15	Base	1
16	Flat Washer	4
17	Hex Head Bolt	4
18	Exhaust Filter	1
19	Square Head Plug	1
20	Control Knob	1
21	1 1/4" x 1 1/4" Pipe Nipple	1




Corsa I Valve Service Kits -




Part No.	Description	Parts Included
	Seal Kit	5, 11, 12, 13, & 14



Corsa I Air Operated Abrasive Valve – with Urethane Sleeve




Item	Description	Qty
1	Top	1
2	Anti-Vibration Washer	1
3	Stop Ring	1
4	Spring	1
5	Piston Seal	1
6	Plunger Cover	1
7	Nylon Washer	1
8	Piston	1
9	Tungsten Plunger	1
10	Cylinder	1
11	Plunger Seal	4
12	O-Ring	2
13	Bush	1
14	Urethane Sleeve	1
15	Base	1
16	Flat Washer	4
17	Hex Head Bolt	4
18	Exhaust Filter	1
19	Square Head Plug	1
20	Control Knob	1
21	1 1/4" x 1 1/4" Pipe Nipple	1



Corsa II Valve Service Kits -

Part No.	Description	Parts Included
	Seal Kit	5, 11, 12, 13, & 14







Corsa II Air Operated Abrasive Valve - with Tungsten Sleeve



Item	Description	Qty
1	Top	1
2	Anti-Vibration Washer	1
3	Stop Ring	1
4	Spring	1
5	Piston Seal	1
6	Plunger Cover	1
7	Nylon Washer	1
8	Piston	1
9	Tungsten Plunger	1
10	Cylinder	1
11	Plunger Seal	4
12	O-Ring	2
13	Bush	1
14	Tungsten Sleeve	1
15	Seat	1
16	Seat Holder	1
17	'O' Ring	1
18	Base	1
19	Flat Washer	4
20	Hex Head Bolt	4
21	Exhaust Filter	1
22	Square Head Plug	1
23	Control Knob	1
24	1 1/4" x 1 1/4" Pipe Nipple	1



Corsa II Valve Service Kits -




Part No.	Description	Parts Included
	Seal Kit	5, 11, 12, 13, & 14




Corsa II Air Operated Abrasive Valve – with Urethane Sleeve



Item	Description	Part No.	Qty
1	Top		1
2	Anti-Vibration Washer		1
3	Stop Ring		1
4	Spring		1
5	Piston Seal		1
6	Plunger Cover		1
7	Nylon Washer		1
8	Piston		1
9	Tungsten Plunger		1
10	Cylinder		1
11	Plunger Seal		4
12	O-Ring		2
13	Bush		1
14	Urethane Sleeve		1
15	Base		1
16	Flat Washer		4
17	Hex Head Bolt		4
18	Exhaust Filter		1
19	Square Head Plug		1
20	Control Knob		1
21	1 1/4" x 1 1/4" Pipe Nipple		1



Corsa II Valve Service Kits




Part No.	Description	Parts Included
	Seal Kit	5, 11, 12, 13, & 14



Exhaust Diaphragm Valve Parts List




Item	Description	Qty
1	Reducing Bush	1
2	Barrel Nipple	1
3	Valve Body	1
4	Diaphragm	1
5	Cap	1
6	Spring Washer	4
7	Bolt	4
8	Washer	4





Fina 1 Abrasive Valve



Item	Description	Qty
1	Control Knob	1
2	Spring Pin	1
3	Bolt 5/16" UNC	2
4	M8 Flat Washer	2
5	Top Body	1
6	Plunger	1
7	Valve Body	1
8	Plunger Seal	1
9	Urethane Sleeve	1
10	Gasket	1
11	O Ring	1
12	O Ring	2
13	Pipe Nipple 1 1/4" - 1 1/4"	1

Fina 1 Valve Service Kit -


Part No.	Description	Parts Included
	Seal Kit	5, 11, 12, 13, & 14



Fina II Abrasive Control Valve



Item	Description	Qty
1	Spring Pin	1
2	Control Knob	1
3	Machine screw 5/16" UNC	2
4	M8 Flat Washer	2
5	Top Body	1
6	O Ring	2
7	Plunger	1
8	Plunger Seal	1
9	O Ring	1
10	Split Pin	3
11	Valve Body	1
12	Plug 1" BSP	1
13	Urethane Sleeve	1
14	Polyurethane Gasket	1
15	Half Ring Clamp	1
16	Spring washer 1/4"	2
17	Socket head machine screw	2
18	Pipe Nipple 1 1/4" - 1 1/4"	1





Fina II Valve Service Kit -

Part No.	Description	Parts Included
	Seal Kit	5, 11, 12, 13, & 14



Helix Remote Control Valve



Helix Remote Control Valve Service Kit

Item	Description	Qty
1	Helix 150 BSP Valve Assembly	1
2	Helix 50 BSP Outlet Valve	
3	Helix 50 Sub Assembly	
4	Nylon Lock Nut - M8	
5	Cylinder Cap	
6	Flat Washer	
7	M8 4 Spring Washer	
8	M8 4 Hex Head Machine Screw	
9	Hex Nipple	
10	Helix 100 BSP Inlet Valve	
11	Helix 100 Sub Assembly	
12	Hex Nipple	
13	1/4" 1 Socket Head Screw	
14	Cylinder Cap	
15	Cap Gasket	


Part No.	Description	Parts Included
	Seal Kit	5, 11, 12, 13, & 14



UniFlow Remote Control Valve Parts List



Item	Description	Qty
1	Valve Body	1
2	Exhaust Chamber	1
3	Exhaust Pad	1
4	Piston	1
5	Diaphragm	1
6	Backing Washer	1
7	Piston Rod	1
8	Bush	1
9	Spring	1
10	Piston End Cap	1
11	Retaining Disk	1
12	M6 Screw	1
13	M6 Screw	1
14	Circlip	1
15	O Ring	1
16	O Ring	1
17	O Ring	1
18	M8 Hex Head Bolt	4
19	M8 Washer	4
20	Nipple 3/4" BSP	1
21	Nut 3/4" BSP	1
22	Quick release coupling male	1
23	Quick release coupling female	1
24	Quick release coupling female	1
25	Quick release coupling male	1
26	Ball valve 1/4"	1
27	Hose clamp	2
28	Hex plug	1



UniFlow Remote Control Valve Service Kit

No.	Description	Parts Included
UNI SK	Service Kit	3, 5, 15, 16 & 17